



## Service Bulletin

### **EAS 911 LCD Display Improvement**

The optimum viewing angle for the liquid crystal display (LCD) on the EAS 911 is the “4 o'clock” position.

The readability of the LCD and its appearance are extremely dependent upon the vertical location of the EAS 911 in an equipment rack.

The readability can be effected by adjusting the LCD contrast in Setup Menu Item 20. The contrast ratio has a range from “0” to “3”. This adjustment should be made only after the EAS 911 is installed in its normal operating location.

*If you have additional tech support questions, contact Customer Service at: [info@tftinc.com](mailto:info@tftinc.com)*